


Assembly Instructions:



www.petgravity.store

petgravity®

SPEEDY SPRINT BALL



Blue

User Instructions:

Short press the button to power on/switch speed/power off.

1. Low-speed: Light green/Light blue.
2. High-speed: Dark green/Dark blue.

Long press the button to switch between normal and smart modes. Please make sure the ball is running before switching.

1. Normal Mode: Auto-off in 5 mins.
Long press the button until the light turns into green.
2. Smart Mode: Auto-standby in 5 mins, reactivate by tapping.
Long press the button until the light turns into blue.

Charging Indicator:

Flashing red light: Low battery

Flashing blue light: Charging

Steady green light: Fully charged



Guidelines&Warnings: This product is not indestructible and should be used under supervision at all times when playing. Regular checks for damage due to wear and tear are recommended. Discontinue use if any damage or loose parts become apparent.